




KitchenAid®

KDFS224S

THIRD LEVEL UTENSIL RACK DISHWASHER
WITH 30+ TOTAL WASH JETS, 47 DBA

Dimensions: h: 33.625" w: 23.9375" d: 24.5"

Colors:  Black  PrintShield Stainless  White



START THE CONVERSATION

How often do you have to scrub your dishes before you put them in the dishwasher to clean your dishes?


TOP FEATURES



1

30+ TOTAL WASH JETS

Provide total cleaning coverage for dishes in each rack with more than 30 targeted jets across three wash arms, so you can load without pre-rinsing.



2

THIRD LEVEL UTENSIL RACK WITH WATER REPELLENT TECH

provides additional space for long and flat items like silverware, serving utensils and spatulas. This rack also features a specialized Water Repellent Technology designed to repel leftover water droplets for dryer utensils.



3

TRIPLE FILTRATION SYSTEM

uses three levels of filtration to remove food particles during the wash and rinse cycles, so your dishes come out sparkling even with dirty cookware in the load.

DID YOU KNOW?

Consumers overwhelmingly prioritize wash performance as a top need for their dishwasher. The top 5 of 6 concerns all relate to cleaning performance*.

*Source: Dishwasher Habits, Practices, Needs & Gaps 2024

HOW TO DEMONSTRATE



30+ TOTAL WASH JETS

Open the dishwasher and point out the 3 spray arms and explain that all those 30+ wash jets ensure dishes are cleaned with their total coverage targeted spray.

ADDITIONAL PRODUCTS TO CONSIDER

Be sure to tune into your customers' shopping priorities to bundle products across categories

ALSO AVAILABLE / STEP UP
[KDPS324S](#)