



KitchenAid®

KDTS324S

THIRD LEVEL JET RACK DISHWASHER WITH
40+ TOTAL WASH JETS, 41 DBA

Dimensions: h: 33.625" w: 23.9375" d: 26.75"

Colors:  Black Ore  Black  Juniper

 PrintShield Stainless  White



START THE CONVERSATION

How often do you have to scrub your dishes before you put them in the dishwasher to clean your dishes?

TOP FEATURES



1

40+ TOTAL WASH JETS

provide complete cleaning coverage for dishes across all three racks, eliminating the need for pre-rinsing. With more than double the number of jets* than the leading competitor's third rack model, it ensures targeted cleaning for dishes on every level.

2

*Compared to Bosch SHX9PCM5N THIRD LEVEL JET RACK

uses over a dozen dedicated wash jets to clean inside coffee mugs and cereal bowls. It also features a removable utensil tray.

3

PRODRY™ SYSTEM

combines a heating element, water repellent tech, and natural ventilation to give you dry, table-ready dishes. To activate, select the ProDry™ Option or ProDry™ Max Option.



DID YOU KNOW?

Consumers overwhelmingly prioritize wash performance as a top need for their dishwasher. The top 5 of 6 concerns all relate to cleaning performance.

*Source: Dishwasher Habits, Practices, Needs & Gaps 2024

HOW TO DEMONSTRATE



40+ TOTAL WASH JETS

Open the dishwasher and point out the 4 spray arms and explain that all those 40+ wash jets ensure dishes are cleaned with their total coverage targeted spray. Only the KitchenAid 6 & 7 series have more spray jets and wash arms

ADDITIONAL PRODUCTS TO CONSIDER

Be sure to tune into your customers' shopping priorities to bundle products across categories



ALSO AVAILABLE / STEP UP
KDTS424S